



Note: In the following text, the term meter refers to both the heat meter and the cooling meter unless they are otherwise differentiated.

1. General

1.1 Use

The T230 is used as a meter for heating or cooling consumption measurement in systems with water.

The meter consists of a high-tech plastic volume measurement unit, two temperature sensors connected in a fixed position and an electronic unit that calculates the energy consumption from the volume and temperature difference.

The meter combines modern microcomputer technology with innovative ultrasonic measuring technology for which no mechanically moving parts are necessary.

This technology is thus wear free, robust and largely maintenance free. High precision and long-term stability guarantee precise and equitable cost accounts.



Note: The meter cannot be opened without damaging the security seal.

1.2 General notes

The meter left the factory in a faultless condition where safety is concerned. The manufacturer will provide additional technical support on request. Calibration relevant security seals on the meter must not be damaged or removed. Otherwise the guarantee and calibration validity of the meter will lapse.

- Keep the packaging so that you can transport the meter in its original packaging following expiry of the calibration validity.
- Lay all cables at a minimum distance of 500 mm to high voltage and high frequency cables.
- A relative humidity of < 93% at 25 °C is permissible (without condensation).
- Avoid cavitation in the whole system due to overpressure i.e. at least 1 bar at qp and approx. 2 bar at qs (applies for approx. 80 °C).

2. Safety Information



The meters may only be used in building service engineering plants and only for the applications described.



The local regulations (installation etc.) must be adhered to.



Adhere to the operating conditions according to the dial plate during use. Non-adherence can cause hazards and the guarantee will lapse.



Do not under any circumstances carrying out welding, drilling or soldering work close to the meter.



The meter is only suitable for circulating water in heating systems.



The meter is not suitable for drinking water.



Adhere to the AGFW requirements regarding circulating water (FW510).



Only personnel, trained in the installation and operation of meters in heating and cooling systems, may install and remove the meter.



Only install or remove the meter when the pipes are pressure-less.



After installing the meter, check the leak-tightness of the system.



Guarantee and calibration validity will lapse if the calibration relevant security seal is broken.



Only clean the meter from outside with a soft, lightly wetted cloth. Do not use any spirit or cleaning solvent.



As far as disposal is concerned, the meter is a waste electronic appliance in the sense of European Directive 2012/19/EU (WEEE) and it must not be disposed of as domestic waste. The relevant national, legal regulations must be observed as the appliance must be disposed of via the channels provided for this purpose. The local and currently valid legislation must be observed.



The meter contains lithium batteries. Do not dispose of the meter and the batteries with domestic waste. Observe the local stipulations and laws on disposal.



You can return the lithium batteries to the manufacturer for appropriate disposal following use. When shipping please observe legal regulations, in particular, those governing the labelling and packaging of hazardous goods.



Do not open the batteries. Do not bring batteries into contact with water or expose to temperatures above 80 °C.





The meter does not have any lightning protection. Ensure lightning protection via the in-house installation.

3. Installation



To install the meter proceed as follows:

- Determine the place of installation in line with the inscription on the meter.



Note: At a **heating meter** the mounting place of the flow sensor cold side is equivalent to return . The mounting place of the flow sensor hot side is equivalent to flow .



Note: At a **cooling meter** the mounting place of the flow sensor hot side is equivalent to the return . The mounting place of the flow sensor cold side is equivalent to flow .

- Observe the dimensions of the meter and check whether there is sufficient space available.
- Rinse the system thoroughly before installing the meter.
- Fit the meter vertically or horizontally between two slide valves so that the arrow on the housing and the flow direction match. Also observe the installation situations and the following examples of installation.



Note: Only use the rubber EPDM flat seals that are supplied.

- The meter must not be exposed tensions or forces caused by pipes or fittings. If this cannot be permanently guaranteed, it is necessary to improve the point of installation or fix the lines in position, by means of suitable connecting brackets for example.
- Fit the temperature sensors in the same circuit as the meter. Observe the admixtures.
- Seal the temperature sensor and the fittings to protect against manipulation.
- If you install the meter for cooling metering, follow the appropriate notes.

Recommendation: If you are installing several meters, the same installation conditions must be consistent for all meters.

Installation Notes

Note: When installing the meter the locally applicable installation regulations for meters must be observed.

Inlet or outlet sections are not necessary. If you install the meter in the common return of two circuits, determine a place of installation with a minimum distance of $10 \times \text{DN}$ from the T-piece. This distance ensures a good thorough mixing of the different water temperatures. You can install the temperature sensors in T-pieces, ball valves, directly immersed or in pockets depending on the version. The temperature sensor ends must reach to at least the middle of the pipe cross section.

Note: Protect the meter against damage through impacts or vibrations at the place of installation.

- On activation, open the slide valves slowly.
- The meter is made of a robust and very stable material.
- Only use open ended spanners to fit the meter. Only insert the open ended spanner on the holding surfaces provided.
 - The maximum range of the tightening torque from 15 Nm for $\frac{3}{4}$ " meter thread or 25 for 1" meter thread must be adhered to during installation. For aligned pipe joints an angle of rotation of the coupling nut from $120 \dots 180^\circ$ ($\frac{3}{4}$ ") or $90 \dots 120^\circ$ (1") from contact of the seal with coupling nut is sufficient.

Recommendation: Do not install the meter on the pressure side of a pump. Maintain a minimum distance of $10 \times \text{DN}$ on the pressure side.

Note: During installation it must be ensured that no water can enter the electronic unit during operation.

Examples of installation (directly immersed sensor)

You can install the meter in any position e.g. vertically or horizontally. In order to avoid accumulation of air and disruption in operation, fit the meter in a vertical installation position and not in the uppermost area of a pipeline.




Fig.1

* This position is not permitted for cold meters and in cases where moisture can enter the electronic unit due to condensation (e.g. during an interruption in the summer).




Fig. 2




Fig. 3: Installation for circulation with admixing; placement of temperature sensors




Fig. 4: Installation for circulation with throttling configuration for example (flow sensor in flow direction before control valve / differential pressure regulating valve)

Installation notes for sensor adapter set

A mounting set is included for meters with 5.2×45 mm temperature sensor. With this you can fit the temperature sensor directly immersed into an insert or a ball valve for example.

1. Install with O-ring at the point of installation with the fit-up aid/pen provided.
2. Place both halves of the plastic bolting round the 3 notches of the temperature sensor.
3. Press the bolting together and screw the bolting hand tight into the point of installation until it comes to a stop (tightening torque 3 ... 5 Nm).




Fig. 5: Mounting adapter set

3.1 Installation for cooling metering

Fit the electronic unit separate to the volume measurement unit, e.g. on the wall for water temperatures below 10°C . Make a loop downwards in order to prevent condensation running along the connected lines into the electronic unit. Install the temperature sensors into the pipe from below.

Note: Wall adapter plates are available as an accessory.

3.2 Electronic unit

The ambient temperature of the electronic unit must not exceed 55°C . Avoid direct sunlight.

Aligning electronic unit

Proceed as follows to align the electronic unit:

- Turn the electronic unit to the left or right through 90° or through 180° as required.

Note: When turning through 45° the electronic unit is not connected tightly to the volume measurement unit.

Wall fitting (split fitting)

Fit the meter to the wall at water temperatures below 10 °C. Proceed as follows:

- Fit the wall adapter plate (available as an accessory).
- Turn the electronic unit through 45°.
- Pull the electronic unit away from the volume measurement unit.
- Place the electronic unit on the wall adapter at an angle of 45° and turn it into position.

3.3 Power supply

The meter is equipped with a long life battery for 6 or 11 years of operation. You can take the operating time from the dial plate.

Warning: Do not open the batteries. Do not bring battery into contact with water or expose to temperatures above 80 °C. Dispose of used batteries at suitable collection points.

3.4 Interfaces and Communication

The meter is equipped with an optical interface in accordance with EN 62056-21 as standard. If the meter is equipped with the option "M-Bus", it is supplied with a 2-wire cable which you can extend by fitting a junction box.

3.5 Temperature sensor

Note: Wires must not be separated, shortened or extended.

4. Operating

Note: Both display range and data displayed can differ from this description depending on the appliance parameterisation. Certain button functions can also be blocked.

The meter consists of a 7-digit LCD displaying various values.




Fig.6: LCD

Number	Description
1	Identification previous year value
2	Previous year value
3	Maxima
4	Previous month value
5	Identification previous month value
6	Activity display at flow
7	Calibrated value

Switching the display

Proceed as follows to switch between the display values:

- Press the button briefly (for less than 2 sec.) to show the next line of the current loop.

After the last line is displayed, the first line comes up again.

- Hold down the button (longer than 3 sec.) in order to display the next loop.

After the last loop is displayed, the first loop comes up again.

If you do not operate the meter for 30 sec. in the user loop "LOOP 0", the meter changes to the standard display. If you do not operate the meter for 30 min. in the loops "LOOP 1 ... 4", the meter changes to the standard display.

User loop "LOOP 0"

LOOP 0	User loop		
* 1234567 kWh	Energy quantity	0000000	Segment test
* 1234567 kWh	Volume	F:---	In case of error: message with error code

Current values "LOOP 1"

LOOP 1	Current values		
1234 kWh	Current flow	20 K	Temperature difference
300 kWh	Current heat power	bd 1234 h	Operating time with flow
670 °C	Alternate current temperature hot and cold side in 2 s cycles	Fd 123 h	Missing time
460 °C		Pd 1234 h	Time with flow

Previous month's values "LOOP 2"

LOOP 2	Previous month's values		
0 10 2 12 M	Log date	1000 kWh	Max. power in 2 s cycles with date stamp
1234567 kWh	Energy quantity and volume on set day	170 1 12 °C	Max. temperature hot side in 2 s cycles with date stamp
1234567 kWh	Missing time on set day	170 2 12 °C	Max. temperature cold side in 2 s cycles with date stamp
Fd 123 h		660 °C	
3000 kWh	Max. flow on set day in 2 s cycles with date stamp	170 2 12 °C	
170 1 12 °C			

General/Communication "LOOP 3"

LOOP 3	General/Communication		
1234567 G	Device number, 7-digit	0 10 1 --	Yearly set day
Mbus	Optional interface	0 1 -- -- M	Monthly set day
127 A	Primary address (only for M-Bus)	1 7-14 FW	Firmware version
0000000 A	Secondary address 7-digit - for M-Bus	CRC-ERR	CRC-Code

Other "LOOP 4"

LOOP 4	Other		
0002 12 M	Date	----	Code entry for test / para operation
105959 T	Time		

4.1 Monthly values

The meter stores the following values for 24 months on the monthly set day

- Missing time
 - Volume
 - Energy
- and the maxima with date stamp for
- Flow
 - Power
 - Temperature hot side
 - Temperature cold side

4.2 Parameterisation

When the LCD displays the code entry, you can call up the parameterisation operation by inputting the code. You can set date and M-Bus primary address in the parameterisation operation for example. For more detail see separate parameterisation instruction.

5. Getting Started



For activation proceed as follows:

- Open the slide valves slowly.
- Check the heating system for leak-tightness and bleed air out carefully.
- Press the button on the meter briefly.

The message "F0" disappears after 10 sec.


- Check the measured values for flow and temperatures for plausibility.
- Vent the heating system until the flow display is stable.
- Fit the user locks to the fittings and the temperature sensors. The scope of supply includes two self lock seals for sealing a sensor and the connecting fitting.
- Read the meter status for energy, volume, operation and missing time and note the values.

Error messages for incorrect installation:


	Error "incorrect flow direction (negative)" Check that the flow direction arrows on the volume measurement unit match the flow direction of the system. If the directions do not match, turn the volume measurement unit through 180°.
	Error "negative temperature difference" Check whether the sensors are installed correctly. If the sensors are not installed correctly, change the installation position of the sensors. Heat meter: Temperature sensor in the flow-pipe with higher temperatures; temperature sensor in return-pipe with lower temperature Cooling meter: Temperature sensor in the flow-pipe with lower temperatures; temperature sensor in return-pipe with higher temperature

Functional Details

If the respective operation thresholds are exceeded and flow and temperature difference are positive, the meter summates the energy and the volume.



If the operate margin is gone below a "u" is displayed at a leading point for the flow, power and temperature display.

For a positive flow the activity display  appears in the user loop in the LCD.

All segments of the display are switched on for control purposes during the segment test. The flow, power and temperature difference are recorded with the appropriate +/- signs.

The operating hours are counted from the first connection of the power supply. The meter saves "operating time with flow" as soon as a positive flow is recognised. Missing hours are summated if there is a fault and the meter is thus unable to take a measurement.

Stored maximum values are marked with an "M" in the lower right hand area of the LCD.

6. Error codes

The meter continuously runs a self-diagnosis and can thus recognise and display various installation or meter errors:

Error code	Error	Service guidelines
FL nEG	Incorrect flow direction	Check flow or installation direction; correct if necessary
if necessary in exchange with:		
DIFF nEG	Negative temperature difference	Check installation point of the temperature sensors; exchange if necessary
if necessary in exchange with:		
F0	No flow can be measured	Air in the measurement unit/pipe, bleed air from pipe (delivery condition)
F1	Interruption in the hot side temperature sensor	Inform service department
F2	Interruption in cold side temperature sensor	Inform service department
F3	Electronics for temperature evaluation defective	Inform service department
F4	Battery flat	Inform service department
F5	Short-circuit hot side temperature sensor	Inform service department
F6	Short-circuit cold side temperature sensor	Inform service department
F7	Error in the internal memory holding	Inform service department
F8	Errors F1, F2, F3, F5 or F6 for longer than 8 hours, recognition of attempts to manipulate. No further measurements are carried out.	Measure dependent on error code. Error message F8 must be reset by service department.
F9	Error in the electronics	Inform service department

7. Technical Data



Note: The information on the meter must be observed!

General

Measuring accuracy	Class 2 or 3 (EN 1434)
Environment class	A (EN 1434) for indoor installation
Mechanical class	M1 *)
Electromagnetic class	E1 *)
*) according to 2004/22/EC Directive on Measuring Instruments	
Ambient humidity	< 93% rel. humidity at 25 °C, without condensation
Max. height	2000 m above sea level
Storage temperature	- 20 ... 60 °C

Electronic unit

Ambient temperature	5... 55 °C
Housing protection rating	IP 54 according to EN 60529
Power supply	Battery for 6 or 11 years
Operation threshold f. ΔT	0.2 K
Temperature difference ΔT	3 K ... 80 K
Temperature measurement range	0 ... 180 °C
LCD	7 digit
Optical interface	Standard, EN 62056-21
Communication	Optional
Separability	Always, cable length 1.5 m

Sensor

Type	Pt 500 according to EN 60751, not detachable
Connection type	Pt 500, 2 wire technology
Cable length	1.5 m (optional 5 m)
Construction type	Bolb sensor \varnothing 5.2 × 45 mm
Temperature range	0 ... 95 °C

Volume measurement unit

Protection class	IP 65 according to EN 60529
Mounting place	Hot side / cold side
Installation position	Any
Flow straightening	None
Measuring range	1:100
Temperature range	5... 90 °C
	National type approvals may be different.
Maximum overload	qs = 2 x qp, permanent
Nominal pressure	PN16 (1.6 MPa, PS16)

qp m³/h

0.6	110 mm (3/4")	
1.5	110 mm (3/4")	130 mm (1")
2.5		130 mm (1")

Overall length and connection

8. Asymmetric mounting (temperature sensor)

The meter can be mounted asymmetric, too. This means one temperature sensor is directly immersed in the volume measuring tube, whereas the other temperature sensor is mounted in a protection pocket. For the lower value of the temperature difference is then 5 K valid at the respective lower flow limit q_i . At this kind of installation the mentioned protection pockets must be used.

Furthermore the national regulations of the respective country have to be observed.

Type of protection pocket	Inside diameter [mm]	Rack length [mm] from upper edge [mm]	Thread size
SPX/50/5,2	5.2	42	1/2"
WZT-M35	5.2	46	1/2"
JUMO 00420848	5.2	46	1/2"
WZT-M50	5.2	50	1/2"
JUMO 00326403	5.2	50	1/2"
1/2" SPX-TH *)	5.2	37	1/2"

*) The sensor pocket must be installed in isolation.

EC Declaration of Conformity

No. CE T230 007 / 06.16



Product description: Ultrasonic heating meter
ULTRAHEAT[®] T230

Manufacturer: Landis+Gyr GmbH, Humboldtstraße 64, 90459
Nuremberg, Germany

Landis+Gyr GmbH takes sole responsibility for the issue of this declaration of conformity. It declares herewith that the above named product meets the requirements of the following directives and laws:

2014/30/EU (EMC) OJ L 96 29/03/2014
2014/32/EU (MID) OJ L 96 29/03/2014
2011/65/EU (RoHS) OJ L 174 01/07/2011
1999/05/EC (R&TTE) OJ L 91 07/04/1999

These respective harmonised standards and normative documents were taken as a basis:

Standard	Last revised	Directive	Reference
DIN EN 61000-6-3	2011	EMC	OJ C 053 25/02/2014
2014/32/EU	2014	EMC/MID	OJ L 96 29/03/2014
DIN EN 1434-4	2007	EMC/MID	OJ C 218 24/07/2012
DIN EN 1434-5	2007	MID	OJ C 218 24/07/2012
EN 300 220-1	2006 ⁶⁶⁸	R&TTE	
EN 300 220-2	2007 ⁶⁶⁸	R&TTE	OJ C 406 14/11/2014
EN 301 489-1	2008 ⁶⁶⁸	R&TTE	OJ C 406 14/11/2014
EN 301 489-3	2002 ⁶⁶⁸	R&TTE	OJ C 406 14/11/2014

Environmental class for MID and EMC E1 or A

The notified authority PTB, 0102) has tested the technical design and certified that it meets the requirements applicable for the device and has issued the following certificate: DE-11-MI004-PTB004 and DE-11-MI004-PTB003

The notified authority (PTB, 0102) has evaluated the quality assurance system and recognises it in: DE-M-AQ-PTB006

Nuremberg, 17/06/2016

Brunner, VP BL HEAT

Name, Position

Signature

Fuchs, Head R&D

Name, Position

Signature

This declaration certifies conformity with the stated directives and standards, it does not however constitute a commitment to any specific properties!
The safety instructions included in the product documentation must be followed!