



de Montageanleitung
en Mounting instructions
fr Instructions de montage
sv Monteringsinstruktion
nl Montagehandleiding
it Istruzioni di montaggio
fi Asennusohje
es Instrucciones de montaje
da Monteringsvejledning
pl Instrukcja montażu
cz Montážní návod
hu Szerelési útmutató
el Οδηγίες εγκατάστασης
zh 安裝指導

Aufbausatz
Mounting kit
Kit de montage
Monteringsssats
Opbouwset
Accoppiamento
Asennussarja
Equipo de montaje
Montasjesats
Zestaw montażowy
Montážní sada
Összeépítő készlet
Μοχλισμός εγκατάστασης
安裝套件




ASK33


SQK33..., SQL33..., SQL83...
 VKF41...
 K1i... (►2006)




1a SQK33...
 SQL33...
 SQL83...




2





1b VKF41...





VKF41...



SQK33..., SQL33..., SQL83...



N SQK33..., SQL33...
G SQL83...



N: SQK33...
SQL33...
G: SQL83...

	11, 12	Y1, Y2	N	G
de	Endschalter	Stellsignal	Neutralleiter	Systempotential
en	End switch	Control signal	Neutral	System potential
fr	Contact fin de course	Signal de commande	Neutre	Potentiel du système
sv	Ändlägeskontakter	Styrsignal	Nolledare	Systempotential
nl	Eindschakelaar	Besturings-signaal	Nul	Systeem-potentiaal
it	Contatto fine corsa	Segnale di comando	Neutro	Fase del sistema
fi	Rajakytkin	Ohjausviesti	Nollajohdin	Järjestelmäpotentiaali
es	Final de carrera	Señal de control	Neutro	Fase para equipos
da	Endestopkontakt	Styre-signal	Nulleder	System-fase
pl	Wyłącznik krańcowy	Sygnal sterujący	Przewód zerowy	Potencjał systemowy
cz	Koncový spínač	Řídící signál	Nulový vodič	Systémový potenciál
hu	Végálláskapcsoló	Vezérlőjel	Nulla (N)	Rendszer fázis
el	Τερματικοί διακόπτες	Σήμα ελέγχου	Ουδέτερος	Φάση
zh	末端开关	控制信号	电源零线	额定电源