

de Montageanleitung
en Mounting instructions
fr Instructions de montage
sv Monteringsinstruktion
nl Montage-aanwijzing
it Istruzioni di montaggio
fi Asennusohje
es Instrucciones de montaje

no Montasjeanvisning
da Monteringsvejledning
pl Instrukcja montażu
cs Montážní list
sk Návod na montáž
hu Telepítési leírás
el Οδηγίες Τοποθέτησης
sr Uputstva za montažu

hr Uputstva za montažu
sl Navodila za montažo
ro Instrucțiuni de montare

74 319 0339 0



RMZ791




74 669 0014 0




74 421 077 0



RMZ791



Maße in mm
 Dimensions in mm
 Dimensions en mm
 Mått i mm
 Maten in mm
 Dimensioni in mm
 Mitat mm
 Dimensiones en mm
 Mál i mm
 Wymiary w mm
 Rozměry v mm
 Vylomit' prepážku
 Méretek mm-ben
 Διαστάσεις σε mm
 Dimenzije u mm
 Dimenzije u mm
 Dimenzije v mm



- de: Klemmlasche ausbrechen
- en: Knock out clamp
- fr: Mise en place des clips
- sv: Bottenplattans fästbygel bryts ut
- nl: Klem uitbreken
- it: Eliminare il fermo
- fi: Irrota kiinnityskynsi
- es: Enfrentar bastidor, separar pestañas y atornillar
- da: Laskeplade slås ud
- pl: Wyjąć zaczepty
- cs: Průchodky vylomit
- sk: vylomiť prepážku
- hu: Bevezetése kitörésen keresztül
- el: Επαφή εξουδετέρωσης (knock out)
- sr: Izvadi osigurač
- hr: Izvaditi osigurač

